

Industrial Adhesive

You can replace the old pads that came off the delivery bar. All you have to do is clean the channel where the old pad came off from and glue one of our Diamond coated (20/3038-pad tips) into the clean channel.

